
Body-Solid





BODY-SOLID, Inc. 1900 S. Des Plaines Ave. Forest Park, IL 60130 USA Phone: (708) 427-3555 Fax: (708) 427-3556 www.bodysolid.com

SIB359G OWNER'S MANUAL

HARDWARE ILLUSTRATION


A1.1/2"X31/4" HEX HEAD BOLT	[16PCS]
A2.1/2"X31/2" HEX HEADBOLT	[4PCS]
A3.5/16"X11/4" HEX HEADBOLT	[8PCS]
B1.1/2" NYLON LOCK NUT	[20PCS]
C1.1/2" ROUND WASHER	[40PCS]
C2.1/2"(I.D) WASHER	[40PCS]
C3.5/16"(I.D) WASHER	-[8PCS]
C4.5/16" SPRING WASHER	[8PCS]
D1.1/2" BOLT CAP(9212-024)	[40PCS]
D2.50X75 END CAP(9211-084)	[2PCS]
D3.2"X2"END CAP(9211-087)	[1PCS]
D4.60X50 NYLON BUSHING(9211-033)	[2PCS]

A2 **A3** A1 **B**1 9 C1 C2 C3 C4 0

0


D1 D2 D4 D3






0

SIB359G ASSEMBLY INSTRUCTIONS



ASSEMBLY-STEP 1



SIB359G-092005



ASSEMBLY-STEP 2

THERE IS A RISK ASSUMED BY INNDIVIDUALS WHO USE THIS TYPE OF EQUIPMENT. TO MINIMIZE RISK, YOU MUST FOLLOW THESE RULES:

- 1. Inspect equipment before each workout. Checke that all nuts, bolts, screws and pop pines are in place and fully tightened. Also before use, check cables for signs of wear. Replace all worn parts immediately. Never use machine if any parts are damaged or missing. Failure to follow these rules may resuit in serious injury.
- 2. Keep clear of the cables and all moving parts when the machine is in use.
- 3. Always make sure all Snap Links are closed when doing any cable/pulley exercises.
- 4. Exercise with care. Perform your exercises at a smooth moderate pace; never perform jerky or uncoordinated movements that may cause injury.
- 5. It is recommended that you should workout with a training partner.
- 6. Do not allow children or minors to play on or around this equipment.
- 7. If unsure of proper use of equipment, call your local Body-Solid distributor or the Body-Solid customer service department at
- 8. WARNING: Consult your physician before starting your exercise program. For your own safety, do not begin any exercise program without proper

